

# Overhead Electric Service

## SERVICE DROP

Installed, owned, & maintained by TRW&L  
To Utility Pole

## CLEVIS HEAD (HOUSE KNOB)

Customer owned & maintained

## WEATHERHEAD

Customer owned & maintained

All equipment (except meter) beyond the point of connection is furnished, installed, owned and maintained by the customer

## METER


TRW&L owned and maintained

## METER BOX

Customer owned & maintained

## MAIN SERVICE PANEL

Customer owned & maintained

Key:  
Customer Owned:   
TRW&L Owned: 